


RACE
APPLICATION
ONLY

801

01-04.5 GM DURAMAX 6.6L SINGLE WITH HANGERS



10114 (8' box models only)



- ☐ 1-10116(5-2)
- ☐ 1-6199(7-2)
- ☐ 1-10113(5-1)
- ☐ 1-10111(5-1)
- ☐ 4-LJ400
- ☐ 1-10114(5-2)

**THIS PART IS FOR USE ON
NON-REGISTERED RACE VEHICLES
ON CLOSED-COURSE COMPETITION EVENTS**

INSTALLING OR USING THIS PART ON ANY EMISSION
CONTROLLED VEHICLE (STREET OR OFF-ROAD) MAY
VIOLATE FEDERAL AND/OR STATE EMISSIONS LAWS
AND REGULATIONS

NOT AVAILABLE TO SHIP TO CALIFORNIA

FLO~PRO
PERFORMANCE EXHAUST

PICKED BY: _____

**THIS PART IS FOR USE ON NON-REGISTERED RACE VEHICLES
ON CLOSED-COURSE COMPETITION EVENTS**

**INSTALLING OR USING THIS PART ON ANY EMISSION CONTROLLED VEHICLE (STREET OR OFF-ROAD)
MAY VIOLATE FEDERAL AND/OR STATE EMISSIONS LAWS AND REGULATIONS**

NOT AVAILABLE TO SHIP TO CALIFORNIA

**KIT # 801
2001 -2004.5 GM 4" SINGLE
REMOVAL OF ORIGINAL SYSTEM**


1. Starting at the bottom of the turbo direct pipe, remove the band clamp from the down pipe. Loosen the bolt enough to unlatch the clamp, then pry the clamp away from the flange at three spots with a flat screwdriver or prybar. Remove clamp. **(Note: keep the stock band clamp, as it will be used with the new system).**
2. Cut the exhaust in two places. First the down pipe next to the transmission and second in front of the muffler. Spray the hangers with WD-40 or equivalent and then pry hangers from the rubber isolators and remove the factory exhaust. **(Note: a sawzall or hacksaw is the preferred method of cutting exhaust).**

INSTALLATION INSTRUCTIONS

*****KITS MAY REQUIRE TRIMMING OF EXTENSION/ INTERMEDIATE PIPES. WHEN TRIMMING ANY PIPES, ALWAYS ALLOW FOR 4" OVERLAP FOR SECURE CONNECTION INTO NEXT PIPE*****

1. Install pipe #10111 using the factory turbo band clamp. Snug the clamp down so it will hold the pipe but the pipe can still be moved. Be sure to insert rod into hanger.
2. Install pipe #10113. On **Extended Cab** models this pipe will be trimmed from the front or long end. On **Crew cab** models this pipe will not be trimmed. Bend in pipe is placed below round cross member on frame. Install clamp and snug clamp down so it will hold the pipe but the pipe can still be moved/ rotated with some effort.
3. Install muffler in factory rubber hanger, slip inlet over rear of pipe #10113 or #10114 (**pipe # 10114 is for 8' box models only**) place clamp on the inlet. Snug the clamp down so it will hold muffler but muffler can still be moved with some effort.
4. Install tail pipe #10116 into outlet of muffler, use the factory rubber hanger. Place clamp on outlet of muffler. Snug the clamp down so it will hold tail pipe but tail pipe can still be moved with some effort.
5. **Check for clearances, i.e. brake lines may have to be moved or e-brake cables as well as axle vent tube.** Also check to make sure that the exit of tail pipe is level with truck.
6. Starting with pipe #10111, tighten turbo band clamp then, starting at front clamp work your way to the back connection, tightening as you go.

Note: a mig weld should be applied to the clamped connections of pipe for added security. DO NOT WELD CLAMPS.



orientation shown of pipe
#10113 under cross
member and towards drive
shaft

Technical Support: 1 800 762 4286 or email, techsupport@flopro.com